
SPEC RICO Instruments



CPI and 2D-S

Cloud Particle Imager



Raw Data Files and Software will be Archived

CPIView Software

Produces: Time series

PSDs

Conditional PSDs


Updated Versions Archived as Available

Coming CPIView Updates

 Special RICO Version under Construction (Taking advantage of spherical shape)

•Probe Bead Calibration is Underway (See WIKI for details)

2D-S



Raw Data Files and Software will be Archived

2DSView

Software

Produces: Time series

PSDs


Fishing Statistic

Updated Versions Archived as Available. Current code is very crude. Sizes Uncorrected.


Coming 2DSView Updates


- Size corrections based on diffraction theory and probe modeling.
- Conditional Sampling: EG:
 - 1. Stereo Particles only.
 - 2. In-Focus Particles only.
- Oh so many more Challenges!

Compared with 2D-S, 2D-C sees 2% of Drops 60 to 130 µm



2D-S Size (µm)	2D-S Cnts	2D-C Size (µm)	2D-C Cnts
10	181273	6 1	
20	95271	25	0
30	27989	20	
40	6075		
50	1992	50	30
60	1166	8	
70	469	75	0
80	326	15	9
90	106		
100	60	100	7
110	19		
120	8	126	0
130	3	125	0
140	0		
150	- 1	150	0





2D-S Vertical and Horizontal Channel Comparison

